



MERITOR

MERITOR FASTSET NO-REAM KING PIN KITS

New Meritor FastSet No-Ream King Pin Kits! This is an economical, high-quality no-ream kit that will significantly reduce repair time. This new kit eliminates the need for reamers, special tools and presses; bushings do not need to be reamed after they are installed into the steering knuckle, which saves labor, time and equipment costs. Instead of pressing in the bushings during installation, customers can use the kit to easily install spiral bushings by hand. Installation can take place at the end user level, making this FastSet kit the easier option to install, maintain and own.



Features & Benefits

No pressing-in of bushings needed during installation

- No reaming necessary on king pin bushings
- Increased strength due to metal-to-metal componentry
- Makes installation faster and easier

Meritor Genuine Kit	Meritor FastSet Kit	Dana Kit	STEMCO Kaiser Qwik Kit	STEMCO Kaiser Plus Kit	STEMCO Kaiser Econo Kit	Dayton Parts Kit	Automann Kit
R201315	R202002	KPK1122	K961L	70.961.12	50.961.12	300-284	460.246B
R201419	R202003	KPK1024	K981R	70.981.18	50.981.18	300-299	460.518C
R201424	R202008	KPK1038	KH946R	78.946.18	58.946.18	300-312	460.526C
R201319	R202010	KPK1140	KG931R	77.931.18	57.931.18	300-332	460.469C
R201312 / R200198	R202011	KPK1121	KH931L	78.931.12	58.931.12	300-265	460.166C
R201474	R202012	KPK1068	K80R	70.080.18	50.080.18	300-316	460.530C
R201307 / R200195	R202014	KPK1119	K931L	70.931.12	50.931.12	300-242	460.204C
R201479	R202021	KPK1049	K70R	70.070.18	50.070.18	300-314	460.532C

* Only on Meritor Applications

Related Parts

- Bushings
- Seals
- T-Handle Tool

Stock up on Meritor King Pin Kits available now through PACCAR PARTS.